



◆Order Code

Order Code	Grease Type	Grease Viscosity	Minimum Order Quantity Requirement
I01D0021	Mobil EP023	NLGI 000	- -
I01D0012	Mobil EP0	NLGI 0	- -
I01D0013	Mobil EP1	NLGI 1	100
I01D0029	Idemitsu Polylex UMF	NLGI 000	6
I01D0030	Idemitsu Eponex IM	NLGI 1	6








◆Features

- 700cc grease cartridge is suitable for KACP-07, KABP-07, KGCP-07, KGNP-07, KGBP-07, KGNBP-07, and POM-AP-07 types grease lubricators.
- Standard 700cc grease cartridge is filled with Mobil grease. Please specify when you place an order if you require a different brand.

◆Notice

- Please discard the empty used grease cartridge and replace a new one. Do not refill grease into the used grease cartridge.
- Please hold the grease cartridge cover tightly to prevent it from popping out by the spring force while disassembling.
- Before replacing a new grease cartridge, lightly squeeze out a little grease in the grease cartridge to prevent air from entering the lubricator.

◆Instruction of Replacing 700cc Grease Cartridge

1		Hold the grease cartridge cover tightly and turn it anticlockwise to disassemble it from the grease cartridge cover base.	5		Assemble the new grease cartridge to the grease cartridge cover base by turning it clockwise.
2		Take the grease cartridge cover out and put it aside.	6		Assemble the grease cartridge cover back to the grease cartridge cover base.
3		Rotate the used grease cartridge anticlockwise to remove it from the grease cartridge cover base and dispose of it properly.	7		Rotate the grease cartridge cover clockwise to assemble it with the grease cartridge cover base to complete the replacement of the grease cartridge.
4		Before replacing a new grease cartridge, lightly squeeze out a little grease in the grease cartridge to prevent air from entering the lubricator.			